

Swegon Home Solutions

CASA[®] R3 Smart



Installation, commissioning and maintenance instruction

Contents

Installation, operation and maintenance instructions for design engineers, installation engineers and service personnel

Important information	3	5.1 Alarm	18
1. General description.....	4	5.2 Troubleshooting	18
1.1 Enclosure	4	6. List of components	20
1.2 Fans	4	7. Technical data.....	21
1.3 Filter	4	7.1 Fan outputs(EN 13141-4)	21
1.4 Heat exchanger.....	4	7.2 Outputs of the components.....	21
1.5 Temperature	4	7.3 Acoustic data.....	22
1.6 Protective safety functions	4	7.4 Electrical wiring diagram	23
2. Installation.....	6	7.4.1 Ventilation unit	23
2.1 Ventilation unit's installation site	6	7.4.2 R3, CASA Jazz cooker hood and control panel	23
2.1.1 Wall mounting	6	7.4.3 Control functions with accessories	24
2.1.2 Ceiling mounting	6	7.4.4 Supervision (DDC)	25
2.1.3 Swegon CASA cooker hood directly connected to the ventilation unit.....	7	7.5 Control diagram	26
2.1.4 Swegon CASA cooker hood separated from the ventilation unit.....	8	7.6 Dimensions	27
2.2 Condensate discharge.....	8	7.7 Weights	27
2.3 Ducts	8	7.8 Ventilation unit codes	27
2.3.1 Commissioning the bypass for the kitchen	8	7.9 Accessories for installation	27
2.4 Sealing around duct penetration collars	9	8. Commissioning form.....	28
2.5 Electric and control cables.....	10	Warranty conditions	29
2.6 Installation of the Smart control panel.....	11	EC Declaration of Conformity	30
3. Commissioning.....	12		
3.1 To set the airflows.....	12		
3.1.1 Setting the fan speeds	12		
3.2 Smart functions	12		
3.2.1 Selection of Smart functions	13		
3.2.2 Automatic Home/Away/Boost system.....	13		
3.2.3 Automatic humidity system.....	13		
3.2.4 Automatic air quality system	13		
3.2.5 Cooker hood function.....	13		
3.3 Sensor	14		
3.4 Control functions with optional items of equipment	14		
3.5 Remote supervision (DDC).....	14		
3.6 Damper motors.....	15		
3.7 Re-heater (not Econo)	15		
3.8 Anti-freeze protection	15		
3.9 Restoring factory settings.....	15		
3.10 To change the service code	15		
3.11 Use	15		
4. Service.....	16		
4.1 Service reminder	16		
4.2 To open the ventilation unit	16		
4.3 Filters.....	16		
4.4 Heat exchanger.....	16		
4.5 Fans.....	16		
4.6 Other servicing.....	16		
5. Alarms and troubleshooting	18		



Important information

Qualified personnel only

Only qualified personnel should carry out installation, configuration and commissioning.

Standards and requirements

The pertinent national standards and regulations dealing with installation, configuration and commissioning must be followed if the equipment is to operate correctly.

At the www.swegonhomesolutions.com address (Toolbox > Find PDF) you will find the document "Project planning instructions for ventilation", in which power supply, sound, airflows and duct system requirements are presented.

Measurement and electrical work

If you carry out voltage tests, measure the electrical insulation resistance at various points or perform other remedial measures that could damage sensitive electronic equipment, you must first isolate the ventilation unit from the electrical supply grid.

Surge protection

Swegon recommends that all ventilation units equipped with Smart automatic control be equipped with a surge protection device.

Earth fault circuit breaker

It is not certain that an earth fault circuit breaker will operate faultlessly in combination with the ventilation unit, since the unit's regulation and control equipment can cause leakage currents. Comply with local electrical safety regulations when you install electrical equipment.

To open the ventilation unit for service

Always ensure that the ventilation unit's power supply has been isolated before you open the inspection door! Wait a few minutes before you open the inspection door on the ventilation unit so that the fans have time to stop and air heaters, if fitted, have time to cool down.

There are no components inside the electrical equipment cabinet that can be serviced by the user. Leave the servicing of these components to service personnel. Do not restart the ventilation unit before you've identified the cause of the fault and service personnel have serviced the ventilation unit.

Drying laundry

A tumbler dryer of extract air type or a drying cabinet must not be connected to the system due to the high moisture content in the air it discharges. However, we recommend the use of a condensing tumbler dryer without duct connection.

Commissioning

Do not commission the ventilation unit until all carpentry work that produces large quantities of sanding dust or other impurities has been completed.

The duct connection spigots of the ventilation unit must be covered by lids while the unit is being transported, kept in storage and mounted at its final location.

Make sure that the ventilation unit, filters and ducts are clean and that there are no loose objects in them before you commission the ventilation system.

Condensation

The surface temperature of the ventilation unit can drop down to 12 °C during periods of frost and depending on the moisture content of the air surrounding the unit, moisture may condense on the surface. Consequently, condensation should be taken into account when choosing furnishings that are to be installed in the vicinity of the ventilation unit.

NOTE! The manual's original language is Finnish.

1. General Description

The most important function of the ventilation system is to ensure clean and fresh indoor air and to remove moisture. The air in the home should be changed at a continuous and sufficient rate to ensure a pleasant indoor climate and avoid damage to building elements caused by dampness. The ventilation unit should be stopped only while service work is in progress.

1.1 Enclosure

The ventilation unit's enclosure class is IP 34 when the inspection door is closed.

1.2 Fans

The Swegon CASA R3 is equipped with energy-efficient fans with EC motors, advantageous in that their speed is variably controllable and their efficiency is high even when they operate in the lower speed range. The power supply and control cables of the fans have quick-fit connectors making the fans easily removable from the unit, if required.

The fans can be controlled in four operating modes from a Smart control panel or in three operating modes from a compatible Swegon CASA cooker hood:

- **Boost** = A large airflow is used when the ventilation requirement increases, e.g. for cooking, taking a sauna, showering or drying laundry.
- **Home** = Normal airflow. Guarantees that there is sufficient fresh indoor air in the home, and that the building construction is at its best.
- **Away** = Low airflow. Reduces power consumption when the ventilation requirement in the home is small.
- **Travelling** = Very low air flow and lower supply air temperature. Used when no one is present in the home. (Can only be selected from a Smart control panel.)

The unit's weekly timer has four programs that can switch in the various fan modes at the preset times. On the unit with electric reheating, you can also select the required temperature of the supply air. Even when the ventilation unit is being controlled with the weekly timer, it is always possible to change the fan mode from a control panel or a cooker hood.

You can select an airflow boost time of 30, 60 or 120 minutes or continuous boost from a Smart control panel. When the unit is controlled from a cooker hood, the fan's airflow boost time is 60 minutes. You can select a damper open time of 30, 60 or 120 minutes.

1.3 Filter

The ventilation unit has class F7 fine filters for the supply air and the extract air.

1.4 Heat exchanger

The ventilation unit is equipped with a rotary heat

exchanger that consists of a rotor whose aluminium fins form a large number of ducts through which the air flow passes. During the heating season, heat that is stored in the ducts on the extract air side is emitted to the cold air on the supply air side. The heat exchanger is motor driven.

1.5 Temperature

The user sets the required value for minimum supply air temperature, and the ventilation unit then strives to reach this temperature if possible. Swegon recommends that the supply air temperature is set between 15–20 °C and the factory setting is 17 °C, which is sufficient for draught-free ventilation. The supply air temperature should be 3–4 °C lower than the room temperature, so that the supply air mixes fully with the room air.

Remember the following when setting the supply air temperature:

- A high temperature setting will also increase the ventilation unit's power consumption.
- A low temperature setting, for example, 14 °C, can cause condensation to collect in the system.
- The ventilation unit cannot cool the supply air without an air cooler (duct coil), which is available as an accessory.

R3's intelligent summer function helps to maintain the home's indoor air comfort even during hot summer days. Very economical comfort coolness can be produced almost free of charge by utilising the difference between indoor and outdoor temperatures and the heat exchanger intelligently. The heat exchanger takes care of the cool indoor air during hot summer days and cools the incoming outdoor air. At night the air passes the heat exchanger and the home is cooled with fresh outdoor air. This is managed by an advanced automatic system.

1.6 Protective functions

The heat exchanger's anti-freeze protection

R3's reliable defrosting function guarantees continuous and balanced ventilation in the home even during extreme conditions. If there is a risk of the heat exchanger in the unit freezing, the speed of the fans is changed and the heated extract air prevents freezing inside the heat exchanger.

The fans' thermal overload protection

The fans have thermal overload cut outs, which stop them if the temperature rises too high. The controller also stops the fans if a serious malfunction occurs in the ventilation unit. The protective function resets itself automatically when the temperature drops or the malfunction has been remedied.

Electric air heater

An automatic thermal overload cut-out switches off the air heater if a fault arises. This protective device automatically resets itself when the air heater has cooled down.

The overheating protection that requires manual resetting can be reset by pressing a button located inside the ventilation unit. The location of the button is marked in the illustration below. When you press the reset buttons and feel a click, the overtemperature protection (thermal overload cut out) has then been reset.

Temperature sensors

If a sensor fault is detected, the ventilation unit enters restricted mode to prevent damage to the ventilation unit. The functions related to the current sensor in question are deactivated and the ventilation unit works as well as possible. The ventilation unit's function returns to normal once the fault has been corrected.



2. Installation

2.1 Ventilation unit installation site

The temperature in the space where the unit will be installed must be more than +10 °C. The ventilation unit can be installed in a machine room, laundry room, store room, etc.

The ventilation unit can also be installed in the kitchen like a wall cabinet above the cooker and a Swegon CASA Jazz cooker hood can be mounted directly to the unit, i.e. connected to the duct connection spigot under the ventilation unit.

The ventilation unit should not be secured to a wall that borders to a living room or a bedroom due to the risk of noise.

During installation, arrange electric and control cables to make them easily accessible.



The ventilation unit can be mounted either on the wall with a wall mounting bracket included in the supply or on the ceiling with a ceiling mounting frame which is available as an optional extra.

The unit should be mounted as near as possible to a wall or ceiling. The space between the ventilation unit and the wall/ceiling must be insulated to prevent the transmission of sound through the wall behind the unit to the adjacent room.

2.1.1 Wall mounting

The wall mounting bracket is supplied together with the unit.

If the wall is composed of vertical studs and wall boards, the wall must be reinforced with horizontal studs that will support the weight of the unit. Swegon also recommends that the wall be insulated with mineral wool or similar insulation for preventing sound from propagating to other rooms.



Wall mounting bracket's dimensions

If the wall is composed of vertical studs and wall boards, the wall must be reinforced with horizontal studs that will support the weight of the unit. Swegon also recommends that the wall be insulated with mineral wool or similar insulation for preventing sound from propagating to other rooms.

Screw the wall mounting firmly in horizontal position onto the wall where a wall stud will support the weight of the unit. Lift up the ventilation unit onto the wall mounting bracket so that the ears on the bracket engage in the corresponding notches at the top on the backside of the unit.

The ventilation unit's inspection door and heat exchanger can be removed to make it easier to lift the unit. The fans can also be removed if necessary. See the "Servicing" Section.

2.1.2 Ceiling mounting


The ventilation unit can also be mounted in a ceiling mounting frame (available as an accessory) on the ceiling.

Fasten the ceiling mounting frame in ceiling anchor sleeves with four M8 threaded rods. The length of rods must be adjusted so that they will be positioned approx. 15-20 mm under the inner surface of the ceiling mounting frame. Install the ceiling mounting frame approx. 35-55 mm below a suspended ceiling.

The ceiling mounting frame must not be used as part of a support structure for the ducts; the duct support must be sufficient even without the support effect provided by the ceiling mounting frame.


Fasten the locking hooks in mounting openings on the ventilation unit's top side by means of tension rivets. Position the hooks so that the sharp point is facing the rear side of the ventilation unit.

The hooks must absolutely not be secured with rivets directly above the ventilation unit.



The points of the hooks face the rear part of the ventilation unit and they are to be slipped into the unit's notches before you secure them with rivets.

Hang the ventilation unit up in the mounting frame so that the rear of the unit engages in the suspension plate. Lift the ventilation unit up against the ceiling mounting frame so that the locking hooks on both sides engage into position. The unit is firmly secured if the screw heads on the front part of the ceiling mounting frame return to their original positions. The ventilation unit can then be secured into position by screwing in the locking screws to their end positions.



1. Suspension plate
2. Locking hooks
3. Lock screw



2.1.3 Swegon CASA cooker hood directly connected to the ventilation unit

The Swegon CASA Jazz cooker hood can be mounted directly against the ventilation unit, and in this case the extract air duct should be connected directly to the duct connection on the bottom of the unit. Secure the cooker hood to the ventilation unit using the screws supplied. The cooker hood is available in right-hand and left-hand versions depending on the ventilation unit's model.

The ventilation unit can be controlled from the cooker hood control panel.




The electric and control cables as well as the connection for the cooker hood's extract air are located under the cover plates in the bottom of the unit.



2.1.4 Swegon CASA cooker hood separated from the ventilation unit

The compatible Swegon CASA cooker hood can be mounted separately from the ventilation unit, and in that case the extract air is conveyed from the cooker hood to an extra duct connection on the upper side of the unit. The duct between the cooker hood and the ventilation unit must be installed in such a way that makes it possible to clean it.

The ventilation unit can be controlled from the cooker hood control panel.



Important



The 100 mm duct connection from the ventilation unit should be fitted with a taper piece for transition to 125 mm as near to the unit as possible.

2.2 Condensate discharge


As a rule, no condensate discharge connection is needed under dry ambient conditions and in combination with a rotary heat exchanger. A certain humidity load exists in homes and a condensate discharge line should be connected to the ventilation unit, if considerable moisture is produced in the home.

Connect the discharge hose to the ventilation unit's condensate discharge connection (3/8" male threads). The condensate must be channelled to a floor drain, the water trap of a sink or the equivalent by means of a tube or a pipe having an inner diameter of at least 12 mm. The tube must not be connected directly to the sewer. The tube must not have a second water trap or be run horizontally. The damming height of the water trap should be at least 100 mm.

The condensate discharge connection is plugged from the outside of the ventilation unit. Remove the plug when you begin using the condensate discharge connection. Check that the condensate discharge outlet is not clogged and check its outflow by pouring water

on the bottom of the ventilation unit. The condensate discharge connection is located on the rear of the unit under the rotary heat exchanger.

The hose for removing condensed water is available as an accessory (part number 502103). The hose has a ready-made loop that serves as a water trap.



There is a metal water trap available as an accessory (UVL).

2.3 Ducts

Install the ventilation ducts, sound attenuators, supply air diffusers, air intake grilles and exhaust air ducts as shown in the ventilation drawings. To prevent the propagation of sound, do not install the ducts directly against structural building elements.

Insulate the ventilation ducts in order to reduce loss of heat or cooling energy and to prevent water from condensing on surfaces. In addition, it is advisable to insulate the ducts to prevent the spread of fire. **It is of greatest importance to insulate cold ducts without gaps in the insulation, so that moisture cannot condense.**



Important



Check whether the ventilation unit has been supplied in the right-hand or left-hand version to make certain that you are connecting the ventilation ducts to the correct duct connection spigots on the unit. Check the ventilation plans to make sure that the duct connections are correctly installed. See also the dimensional drawings in the Section entitled: "Technical data".

2.3.1 Commissioning the bypass for the kitchen

The ventilation unit has extra duct connections for extract air from the cooker hood on its top and bottom sides. The extract air from the cooker hood flows directly out through the unit's extract air fan and does not

pass the heat exchanger. For this reason, the kitchen's general ventilation must not take place via the cooker hood. On delivery, both of the duct outlets that bypass the heat exchanger are fitted with covers.

If the duct connection designed for bypass from the kitchen is used, the duct between the cooker hood and the unit must be installed in such a way that makes it possible to clean it.



Important



The bypass for a kitchen is intended for use when the airflows from the cooker hood/kitchen are boosted. The kitchen's general ventilation must take place via the extract air duct. If the general ventilation takes place continuously via the cooker hood, the supply air and extract air flows through the heat exchanger will be out of balance, and this will lower the efficiency and impair the ventilation unit's anti-freeze protection functions during the winter.

Dismantle the cover panel on the top of the ventilation unit

How to open the ventilation unit and remove the guard plates are described in the section entitled: "Service".

- Open the ventilation unit's inspection door and remove the guard plates in front of the heat exchanger.
- Remove the screws of the guard plate that covers the duct connection.



- Pull out the cover together with its insulation.



- Secure the guard plates for the extract air fan and the heat exchanger with screws at their positions and close the inspection door. The duct connection spigots are now ready for connection to ducting.

Dismantle the cover panel on the bottom of the ventilation unit

How to open the ventilation unit as well as how to remove the guard plates and heat exchanger are

described in the Section entitled: "Service".

- Open the ventilation unit's inspection door and remove the heat exchanger guard plates. Withdraw the heat exchanger from the unit.
- Remove the screws of the guard plate that covers the duct connection.



- Pull out the cover together with its insulation.

Push the heat exchanger back into the unit, secure the guard plate with screws at its position and close the inspection door.



2.4 To seal around duct penetration collars

It is important to preserve the tightness of the vapour barrier at the duct penetration collars. We recommend the use of a mounting frame designed for the ventilation unit (accessory, PR085YP) for sealing the vapour barrier in the loft ceiling beams.

Cut up the openings with approx. 10 mm smaller diameter than that of the ducts. Secure the mounting frame in the ceiling with screws through the holes on the sides. The plastic film of the vapour barrier should either be stretched and fastened between the mounting frame and the structural element of the building, or be taped tightly against the mounting frame.

The thickness of the insulation and the nature of the surface layer of the ventilation ducts vary depending on insulation material, climate zone and national standards in force. For this reason, Swegon does not offer any recommendations for insulation thickness. Most manufacturers of insulation material offer calculation programs for the calculation of sufficient and correct insulation.

In renovation projects, it is advisable to examine the existing ducts to determine whether they are sufficiently and correctly insulated. Insulating in the right way is necessary for the ventilation unit to operate correctly. **If the ducts are uninsulated, even across a small area, there is a high degree of risk of condensation and indirect damage.**

The supply air duct should be fitted with acoustic insulation along the stretch between the unit duct outlet and the sound attenuator, so that fan sound will not be propagated out into the room.

In general, ventilation ducts should be insulated in the following manner:

- Insulate outdoor air ducts run through warm spaces.
- Exhaust air ducts should always be insulated in accordance with national regulations. See separate project planning instructions (for example Fire resistance classification requirements).
- Insulate supply air ducts in cold spaces.
- Insulate extract air ducts in cold spaces.
- If the air inside the duct is colder than in the surroundings; the insulation should be protected by a vapour barrier.



Important



Even small gaps in the insulation impair the sound attenuation and bring about a risk of condensation and consequential damages.



Important



Before commissioning the ventilation system, check that the ventilation unit, filters, condensation drain and ducts are clean and that there are no loose objects inside them. The ventilation ducts should be cleaned regularly and always when the home is renovated.



Important



It is absolutely forbidden to operate the ventilation system during the construction period or if dust-raising work is carried out. Before installing the unit, the ducts should be blanked off with covers to prevent the entry of impurities.

The maximum length of the modular cable in the system is 40 metres. If the modular cable is lengthened within some building element (such as a wall), the cable should be lengthened in a Ø 20 mm dia. tube as a precaution in case the need should arise to replace it in the future.



Important



If any further electrical wiring is required, only a qualified electrician shall be allowed to carry out this work.

The electric and control cables are located on the upper side of the ventilation unit. Make sure that the electric cable can be connected to a wall outlet without obstruction.

When installing the unit, make sure that you provide adequate access to the connector of each cable (loose ones as well), e.g. for servicing and adjusting the unit, if and when the need arises.

In multi-storey buildings, a control panel can be used as a so-called hand-held micro terminal in conjunction with service and installation work.

The connection of possible accessories is described in the wiring diagram in the Section entitled: "Technical data". The cables for accessories are not included in the supply.

2.5 Electric and control cables

A 1.5 m long cable with earthed plug-in contact is fitted to the ventilation unit for measuring the voltage. The cable extends from the top of the unit. The mains plug serves as the ventilation unit's main switch and it should be connected to an electric socket at an easily accessible spot. For power required, see the Section entitled: "Technical data".

There is a modular cable for control on top of the ventilation unit. There is a modular cable for the cooker hood located under the cover plate at the bottom of the ventilation unit.

2.6 Installation of the Smart control panel

A maximum of two Smart control panels can be connected to the ventilation unit, with different mutual ID numbers. A 20 metre long modular cable is included to connect the control panel. Run the cable to the desired place where the panel will be mounted. A Smart control panel can be mounted up to 40 metres from the unit (using 2 x 20 metre long modular cables).

The front panel on the Smart control panel is released using a screwdriver to push the retaining clips through the holes on either side.



The modular cable connected to any outlet socket on the panel.



Finally, refit the front panel.

If several control panels are connected in chain, the middle panel's bus termination is moved to the "Open" position. The jumpers do not need to be adjusted if only one control panel is used.



Bus termination: Terminated



Bus termination: Open

3. Commissioning

The ventilation system's settings in connection with commissioning and servicing are made from the password-protected "Settings" menu on a Smart control panel. To open the menu, enter code 1234. (The code can be changed). In conjunction with commissioning, you always need to set at least the airflow and carry out any adjustments to the Smart sensor if fitted.

◀ Settings
Fan speeds
Preheater
Re-heater
Input settings
Smart functions
Fireplace function
Smart settings
Summer mode
Supply air limit
DDC control
Damper actuators
Sensors
Alarms
Reset factory settings
Change service code

3.1 To set the airflows



For estimated values for setting the airflows, use the sizing curves in the Section entitled: "Technical data". A qualified person should set the ventilation unit's and the ventilation equipment's airflows using appropriate measurement equipment.

As an initial value for ventilation planning, you can use the ventilation value 0.5 times the volume of the building per hour + 6 l/s supply air per person, when the unit is operating in the Home mode. (Initial values can vary in different countries.)

In new homes, there is still construction moisture and the house initially requires higher ventilation in order to remove the moisture from the building. A great deal of moisture in the home manifest itself in the form of moisture on cold surfaces. We recommend that in new houses to use higher volumes of air at first to remove moisture.

All the fan modes must be preset so that the ventilation unit will operate correctly. Fill in your entered settings in the commissioning report.

It is recommended in order to improve the efficiency of the ventilation to use an automatic moisture sensor or to actively use the ventilation unit's boost speed, if there is a sauna, pool or equivalent moisture producer in the home.


Important


Set the fan speeds in accordance with national regulations when you commission the ventilation system. The system should be commissioned by a qualified person, and the airflows must not be changed on one's own responsibility, since doing so could disrupt the way the ventilation system operates.

3.1.1 Setting the fan speeds

Before you start to adjust the fan speeds, ensure that the filters are clean and that there are no foreign objects or debris inside the ventilation unit.

◀ Fan speeds
Commissioning mode <input checked="" type="checkbox"/>
Away (supply) 30%
Away (exhaust) 30%
Home (supply) 50%
Home (exhaust) 50%
Boost (supply) 80%
Boost (exhaust) 80%
Max Smart boost (supply) 100%
Max Smart boost (exhaust) 100%

Choose commissioning mode from the "Fan speeds" menu, as the ventilation fans then run at the speed being set. In commissioning mode, all functions that affect the speed of the ventilation unit's fans, such as the anti-freeze protection, are disconnected.

Set the fan speeds for all operating modes (Home/Away/Boost) and the largest automatic boost, if you wish to limit the Smart functions.

Fill in your entered settings in the commissioning report.

3.2 Smart functions

Setting of Smart functions must be performed.

3.2.1 Selection of Smart functions

Select which functions are to be available from the "Smart functions" menu. When boost is selected, boosting is used on all connected sensors.

Smart functions	
Fireplace function	<input checked="" type="checkbox"/>
Travelling	<input checked="" type="checkbox"/>
Cooker hood function	<input checked="" type="checkbox"/>
Central vacuum function	<input checked="" type="checkbox"/>
Boost	<input checked="" type="checkbox"/>
Summer mode boost	<input checked="" type="checkbox"/>
Heating boost	<input checked="" type="checkbox"/>
Shut down	<input checked="" type="checkbox"/>

3.2.2 Automatic Home/Away/Boost system

The function is available only on models equipped with a carbon dioxide sensor. The automatic control system controls the ventilation airflow variably according to the carbon dioxide level in the home.

This function should always be set in conjunction with commissioning.

Auto Home/Away/Boost	
A+ now	950 ppm
Home limit	900 ppm
Away limit	600 ppm
Filter time	1 min

The settings menu shows the value "**A+ now**" the current level of carbon dioxide. The function is set by defining the limits values Home and Away. A suitable Home limit value can be determined by reading the "**A+ now**" value from the menu when a normal number of people are in the home. Similarly, you can determine the Away limit value by reading the "**A+ now**" value when the property has been empty for several hours.

3.2.3 Automatic humidity system

The function is available only on models equipped with a humidity sensor. The function boosts the ventilation according to the normal moisture load caused by a person, for example, when a shower adds extra moisture to the residence. If the relative humidity of residence rises above 60% over a longer period, the set airflows must be increased, and the reason for the high level of moisture investigated.

Auto humidity control	
RH now	30 %
Boost limit	5 % + RH
Full boost limit	30 % + RH
Sauna function	<input type="checkbox"/>
Sauna boost	5 %

The value "**RH now**", the current moisture level, is shown on the settings menu.

The automatic humidity system measures the daily average value in the extract air and compares this with the current value. The ventilation starts to be boosted variably when the humidity has risen as much as the Boost limit value.

When the sauna is working, the ventilation is boosted with the set value, through the activation of the automatic sauna limitation. This function prevents variations in the fan speeds while the sauna is working.

3.2.4 Automatic air quality control

The function is available only on models equipped with automatic air quality. Automatic air quality boosts the ventilation variably according to the indoor air quality.

This function should always be set in conjunction with commissioning.

Auto Air Quality control	
AQ now	620 ppm
Boost limit	800 ppm
Full boost limit	1400 ppm
Filter time	1 min

The settings menu shows the value "**AQ now**" the current air quality level. The function is set by specifying the boost limits where you want the ventilation boost to start and the value at which you want the ventilation unit to reach maximum boost. Appropriate values can be established based on the "**AQ now**" value shown in the menu.

If it seems that the ventilation system reacts too quickly to changes in the air quality level, you can increase the filtering time.

3.2.5 Cooker hood function

The cooker hood function balances the ventilation when the cooker fan is used to help prevent excessive negative pressure and improves fume extraction capability of the cooker hood. The function starts automatically when the damper in a compatible cooker hood is opened and runs until the damper is closed.

Cooker hood function	
Run time	30 min
Home state Compensation	20%
Boost state Compensation cor.	0%
Allow exhaust fan slowdown	<input type="checkbox"/>

Choose to permit a speed reduction of the extract air fan when using a cooker hood whose extract air does not pass through the ventilation unit.

Enable the cooker hood function and set the Home mode's compensation value so that the airflows are kept in balance. Fine tune the boost compensation value too if necessary.

!
Important
!

The ventilation unit must be equipped with either an internal or external preheater if you want to use the ventilation's balancing functions (fireplace function, cooker hood function, central vacuum cleaner) at temperatures below -10 °C.

!
Important
!

Smart measurements: CO₂, RH ja VOC. The absolute values in the measurement result does not affect how well the control works.

3.3 Sensor

Select which sensor you wish to use to measure the room air temperature.

Sensors	
Room air	UP1
Room air temperature	22,2°C
Room air fine tuning	0,0°C

The menu shows the temperature measured by the selected sensor. If, for example, the temperature measured by the sensor differs from the value from a temperature sensor installed in a different location in the same room, the temperature sensor can be calibrated by changing the room air fine tuning value.

3.4 Control functions with optional items of equipment

If the unit is to be controlled with accessories, set the switch input for this. (See the wiring diagram in the section : "Technical data" / "Control functions with accessories".)

Input settings	
Input 1	Fireplace
Priority	1
Input 2	Hood
Priority	1
Input 3	No selected

There are three switch inputs on the ventilation unit's PCB that need to be configured. Specify which switch is connected to each input. The options are input signals from the following external switches: fireplace, traveling, central vacuum, cooker hood, boost and filter guard. You can change the relative priority of the functions if necessary.

3.5 Remote supervision (DDC)

If the ventilation unit is to be operated remotely, choose to put remote control into service and set the desired temperature reductions. If the ventilation unit's fan control is handled by DDC, you cannot change the operating mode from the Smart control panel. See a detailed description of remote control in the section "Technical data" / "Supervision (DDC)".

Variable control occurs between the voltages 2 V - 5 V - 8 V. The ventilation then switches variably between operating modes Away - Home - Boost. Otherwise, control is performed according to the normal DDC control.

◀ DDC control	
Fan control	<input checked="" type="checkbox"/>
Temperature control	<input type="checkbox"/>
Emergency stop	<input type="checkbox"/>
Temperature drop (away)	0°C
Temperature drop (travelling)	2°C
Stepless control	<input type="checkbox"/>

3.6 Damper motors

If external duct damper motors are used, choose to enable control. The damper is then regulated to the open position when the ventilation unit is operating.

◀ Damper actuators	
Damper actuators	<input type="checkbox"/>

3.7 Re-heater (not Econo)

◀ Re-heater	
In use	<input checked="" type="checkbox"/>

Here you select whether you wish to use the electric air heater for re-heating to heat the supply air when the heat exchanger's power is not sufficient for reaching the preset supply air temperature.

3.8 Anti-frost protection

Anti-frost protection works automatically.

3.9 Restore factory settings

Resets all settings made from the control panel, with the exception of the fan speeds.

3.10 Change the service code

◀ Enter code	
[1 2 3 4]	
Accept	

This menu is used to change the code to access the setting menu.

3.11 Use

Issues with reference to the usage of the ventilation system are dealt with in the instructions for use supplied with the unit.

4. Service

4.1 Service reminder

The service reminder is activated with preset time intervals and the ⓘ symbol is displayed on the control panel's screen. As a factory setting, the service reminder is not in operation. It can be put into operation under the main menu item "Diagnostics"/"Service reminder". The recommended service interval for the ventilation unit is six months.

When servicing has been performed, the service reminder is reset from "Alarm" in the main menu.

4.2 To open the ventilation unit

Before you begin any service work, isolate the power supply voltage to the ventilation unit by pulling out its electric plug from the wall socket. Wait a few minutes before you open the inspection door of the ventilation unit so that the fans have time to stop and possible air heaters have time to cool down.

The lock bolts of the inspection doors are located in the upper and lower edge of the door under the cover plates. The cover plates can be removed by pressing them in and sliding them as shown in the image below.



Open the inspection door by turning the two lock bolts with a screw driver for slotted screw heads. The door can then be carefully lifted off when the lock bolts have been opened.

4.3 Filter

The filters should be replaced at least every six months. The filters may need to be cleaned or replaced more often in homes where there is considerable dust or if there are many impurities in the outdoor air.

The ventilation unit must not be operated without filters. Use only filters recommended by Swegon in the ventilation unit. This is important, as filters with exactly the same appearance and size can have very different pressure losses and filter capacity. If an incorrect filter is used, it is not certain that the ventilation unit will work as designed. Check in the list of components that you have selected correct filters.

4.4 Heat exchanger

You should check the condition of the heat exchanger whenever you service the unit.

You need to check that the heat exchanger has not frozen to the air handling unit's frame during cold

spells. When necessary the air handling unit's inspection doors should be held open for a while before the heat exchanger is removed from the unit, so that the temperatures have time to equalize and to prevent damage to the seals.

Remove the screws of the heat exchanger's guard plate and pull the heat exchanger out to inspect it. If you want to withdraw heat exchanger completely out of the unit, you must also disconnect the quick-fit connector. The contact is located under the extract air filter. When you mount the heat exchanger back in the unit, be sure to reconnect the connector and arrange the cable where it won't become worn by moving parts in the rotary heat exchanger.

There is an opening in the front plate of the heat exchanger through which you can see the drive belt. Carefully rotate the heat exchanger rotor one revolution to inspect the condition of the drive belt. Do not damage the heat exchanger fins.

Check the condition of the brushes along the rotor periphery. Replace the brushes if they are worn.

Make sure that the passages through the heat exchanger rotor are not clogged and clean them e.g. with running warm water if required. Never use cleaning agents. Inside the heat exchanger enclosure there is an electric motor that must not be exposed to dampness. **The passages of the heat exchanger should be dry before you reinstall the heat exchanger in the unit.**

4.5 Fans

The ventilation unit's fans must be checked at least every two years. Withdraw the fans from the unit for inspection. You can remove the fan from the unit by pulling them straight outwards. If you pull the fans out completely, you must also disconnect the quick-fit connector.

In particular, if the cooker hood is mounted directly on the ventilation unit grease and dust can accumulate on the extract air fan impeller and on the walls of the ventilation unit's fan chamber. If dirt builds up in the fans this can affect the functionality of the ventilation unit.

If necessary, clean with a soft brush. Be careful not to dislocate the impeller balancing weights. If significant amounts of dirt collect on the fan impeller cleaning should be left to a professional.

4.6 Other servicing

Clean the inner surfaces of the ventilation unit by vacuum cleaning or with a damp cloth, if needed.

Check that the condensate discharge outlet is not clogged and check its outflow by pouring water on the bottom of the ventilation unit. The condensate discharge connection is located on the rear of the unit under the rotary heat exchanger.




- 1. Supply air filter
- 2. Extract air filter
- 3. Heat exchanger guard plate
- 4. Guard plate

!

Important

!



The ventilation unit must not be operated without filters! Use only filters recommended by Swegon in the ventilation unit. Find the correct filter in the Section entitled: "Technical data".



- 1. Extract air fan
- 2. Supply air fan
- 3. Heat exchanger
- 4. Heat exchanger drive belt

5. Alarms and Troubleshooting

5.1. Alarms












Any disruptions to the function of the ventilation unit are indicated by symbols on the upper row of the base display. If there is an active alarm in the system, the screen leaves its standby mode and does not enter standby mode again as long as the alarm is active. The symbol for an active alarm is . The condition that has caused the alarm is shown by the "Alarm" item on the main menu. A so-called info-alarm remains on the screen when the active fault condition ceases.  The Info alarm can be reset from "Alarm" on the main menu.



Important



Freeze protection function
 Ice can form in the heat exchanger during periods of cold weather if the extract air is humid. A protective function then automatically reduces the speed of the supply air fan. Under such conditions, variations in the fan speed are therefore normal. Under such conditions, small amounts of ice can form inside the ventilation unit.

Status	Alarms	Action
	T1...T8 sensor fault	Contact a service company. The ventilation unit runs in a restricted operating mode.
	Reheater error	Check the overheating protection. Contact a service company.
	Preheater error	Check the overheating protection. Contact a service company.
	Freeze risk water-heated air heater	Ensure that the circulation pump in the waterborne heating system is running and that the water supply to the ventilation unit's heating coil is hot enough.
	Fault supply air fan	Contact a service company.
	Fault extract air fan	Contact a service company.
	Contact fault	Restart the ventilation unit. Contact the service company if the error persists.
	External emergency stop/ fire alarm	The alarm clears automatically when the external emergency stop or the fire alarm ceases. No info alarm remains afterwards.
	Internal fault	Restart the ventilation unit. Contact the service company if the error persists. The ventilation unit runs in a restricted operating mode.
	Service reminder	Service the ventilation unit and acknowledge the service reminder.
	Filter guard	Replace the filter and reset the filter guard.

5.2 Troubleshooting

A ventilation system is a unified whole composed of several system components all of which influence how the system operates. A malfunction in ventilation performance could be caused by any component of the ventilation system or by the way the system has been installed. If during the ventilation unit's warranty period (2 years) after a check (see the enclosed check list) there are functional disruptions in the ventilation unit, you can register these using the response form at the address www.casahep.fi. There are also instructions, service videos and frequently asked questions on the same website.

If a problem or a fault occurs on the ventilation system after the warranty period (2 years), contact our network of authorised service companies on www.swegonhome-solutions.com, your real estate company's service division or another service company that is fully conversant with ventilation repairs.

CHECK LIST

For users of the Swegon CASA ventilation unit

Thank you for your excellent choice of energy efficient ventilation for your home. Swegon designs, manufactures, markets and sells Swegon CASA ventilation units and cooker hoods. Swegon guarantees the functionality of the manufactured units and grants a warranty for them. A ventilation system is a unified whole composed of several system components all of which influence how the system operates. This check list is meant for use by specialists in the building trade and for residents who suspect malfunctions in the ventilation.

Malfunctions in ventilation performance

A malfunction in ventilation performance could be caused by any component of the ventilation system or by the way the system has been installed. Normal operation of the Swegon CASA ventilation unit is described in the user's instructions supplied with the unit on delivery. If malfunctions occur in the ventilation system, ensure the following with the help of a professional:



Items to check



- 1) Make sure that the pipes have been insulated fully according to the instructions and that the insulation reaches all the way up to the ventilation unit so that no uninsulated surface is visible.
-> Even a small gap in the insulation could cause among others condensation and acoustic problems.



- 2) Make sure that the pipes' connections to the ventilation unit are tight and that the unit is installed horizontally.
-> If the connections have not been fitted correctly, condensation and acoustic problems could arise.



- 3) Make sure that the ventilation unit is equipped with Swegon's original filters. This will ensure pressure differentials and the filtration values that conform to the design level, enable the unit to operate correctly and maintain a healthy indoor climate in the home. Make also sure that the filters are clean and replace them when needed. Check also the fresh air grille and clean it if needed.



- 4) Check that there are no unnecessary objects or impurities inside the ventilation unit. At the same time, make sure that the condensate drain in the bottom of the ventilation unit is not clogged by impurities or insects. The condensate drainage function can be checked by pouring a few drops of water on the bottom of the ventilation unit.



- 5) If the ventilation unit is equipped with electric air heaters, make sure that the excess temperature cut-out switches have not tripped. The excess temperature cut-out can be manually reset by pressing a button according to the user's instructions.



- 6) Make sure that the ventilation unit's inspection cover is closed and that it seals tightly along its entire periphery against the unit casing.



- 7) Check that the airflow rate settings have been set according to the ventilation plan and that the airflow rates to and from the ventilation unit's air heater are in balance (the supply air flow must be 2–10 % less than the extract air flow).




- 8) Make sure that the fan speeds have been preset for all the operating modes (Away, Home, Boost). If the fan speed settings do not deviate from the factory settings presented in the instructions, there is reason to suspect inadequate commissioning/adjustments.



- 9) Make sure that a correctly recorded and approved measurement record is available.

If the above-stated checks are not carried out and representatives for Swegon or an authorized service company discover inadequacies in them, the client is responsible for the costs for the service visit, even during the warranty period. If a ventilation unit under warranty is still marred by functional disruptions after the checks, submit a contact request on our web site www.casahelp.fi. If a problem or a fault occurs on the ventilation system after the warranty period (2 years), contact our network of authorised service companies on www.swegonhomesolutions.se, your real estate company's service division or another service company that is fully conversant with ventilation repairs.

6. List of components



1. Temperature sensors *

2. Fan (R Model): PEC119R

2. Fan (L Model): PEC119L

3. Reheating cassette (Model R): PR085REK

3. Reheating cassette (Model L): PR085LEK

4. EC circuit card: 603010

5. Door contact: 60542

6. Set of filters: PR085FS

7. Rotor package (R Model): RP85BR

7. Rotor package (L Model): RP85BL

8. Complete door with white front plate: DR85BRL1

9. Front plate of the front cover (white): PR085B6V

9. Front plate of the front cover (stainless): PR085B6R

10. Lock: 61954

10. Cover plate of the lock (white): 61371

11. Cover plate of the lock (black): 61372

12. Wall mounting bracket: 6010208

Accessories


- Smart control panel: SC10
- Modular cable: PMK20
- Mounting frame with vapour barrier (R/L): PR085YP
- Condensate discharge tube: 502103
- Water trap: UVL
- Ceiling mounting frame (R): PR085RKA
Ceiling mounting frame (L): PR085LKA
- Replacement filter set of 2 filters F7: PR085FS
- Inspection door cover plate (white): PR085B6V
Inspection door cover plate (stainless): PR085B6R
- Swegon CASA Jazz cooker hood for location below the ventilation unit (stainless steel, white)

*) Temperature sensors:


- 750 mm, without connector (T1, outdoor air sensor), R Model: 604924
- 850 mm, without connector (T1, outdoor air sensor), L Model: 604925
- 750 mm, with connector (T3, extract air sensor), R Model: 604915
- 1,000 mm, with connector (T3, extract air sensor), L Model: 604916
- 300 mm, without connector (T4, supply air sensor): 604923
- 1,450 mm, with connector (T5, exhaust air sensor): 604919

7. Technical data

7.1 Fan outputs(EN 13141-4)



Power consumption



Important



The minimum air flow is 25 l/s.
At low air flows you should use the R3-models with the factory mounted humidity sensor.

As air flows in Boost mode, you need to set at least 45 l/s or + 30 % in relation to the air flow in Home mode, depending on which of these options gives the greatest air flow.

7.2 Outputs of the components

	R3	R3 with reheating
Connection	230 V, 50 Hz, 1.0 A	230 V, 50 Hz, 3.2 A
Fans	230 W	230 W
Heat exchanger motor	10 W	10 W
Air heater, reheating	-	500 W
Total output	250 W	750 W
Cooker hood	15 W	15 W
Total output, cooker hood*	265 W	765 W

* Swegon CASA Jazz cooker hood connected below R3.

7.3 Acoustic data

Sound emitted to supply air duct

Fan setting %	Sound power level broken down into octave bands, $L_{w_{okt}}$ dB								Total assessed sound power level L_{WA} dB(A)
	63 Hz	125 Hz	250 Hz	500 Hz	1,000 Hz	2,000 Hz	4,000 Hz	8,000 Hz	
30	57	44	40	39	34	26	13	-	40
40	60	53	46	45	42	36	26	12	47
50	60	57	49	49	46	41	33	20	51
60	64	63	53	52	50	46	40	28	55
70	68	67	57	56	53	50	45	35	60
80	71	71	61	59	56	54	49	41	63
90	74	75	64	62	58	57	52	45	65
100	77	77	67	64	60	60	55	49	68

Sound emitted to extract air duct

Fan setting %	Sound power level broken down into octave bands, $L_{w_{okt}}$ dB								Total assessed sound power level L_{WA} dB(A)
	63 Hz	125 Hz	250 Hz	500 Hz	1,000 Hz	2,000 Hz	4,000 Hz	8,000 Hz	
30	57	46	31	29	24	17	12	-	35
40	57	47	36	34	26	18	12	-	37
50	57	47	40	35	27	18	12	-	37
60	58	48	44	39	31	21	14	-	40
70	58	56	48	42	33	24	17	-	45
80	59	62	52	45	35	27	20	-	49
90	60	65	55	48	38	30	23	13	52
100	62	68	57	50	40	32	25	15	55

Sound emitted to kitchen bypass duct

Fan setting %	Sound power level broken down into octave bands, $L_{w_{okt}}$ dB								Total assessed sound power level L_{WA} dB(A)
	63 Hz	125 Hz	250 Hz	500 Hz	1,000 Hz	2,000 Hz	4,000 Hz	8,000 Hz	
30	60	55	37	33	27	12	-	-	41
40	61	56	43	39	33	23	12	-	44
50	59	57	46	42	37	28	19	-	45
60	61	59	51	46	41	33	26	-	49
70	61	63	55	50	44	37	30	16	52
80	67	66	59	53	47	40	35	22	56
90	69	69	62	56	49	43	37	26	59
100	70	72	65	59	51	45	41	30	61


Sound emitted to the surroundings

Fan setting %	Sound pressure level 10 m ² sound absorption $L_p(10)$, dB(A)*	
	Mounted between cabinet together with the cooker hood	Mounting on a wall
20	22	27
30	23	27
40	24	29
50	25	30
60	30	32
70	31	35
80	34	38
90	36	40
100	40	43

*) Equivalent to a normally insulated room. If sound power level L_{WA} dB (A) values are required, the 4 units (dB) need to be added to the table values.


7.4 Electrical wiring diagram

7.4.1 Ventilation unit




1. Temperature sensor, see the Control diagram
2. Samrt-control panel (accessories)
3. Triac controller
4. Air heater, reheat, 500 W (accessory)
5. Door contact
6. Smart sensor package
 - RH (accessory)
 - RH + CO₂ (accessory)
 - RH + VOC (accessory)

7.4.2 R3, CASA Jazz cooker hood and control panel



7.4.3 Control functions with accessories



1. Fireplace switch
2. Boost timer
3. Humidity sensor
4. Timer
5. Compensation for negative pressure
6. CO₂ sensor with relay
7. CO₂ sensor
8. Damper actuator for duct damper – A outdoor air duct*
9. Damper actuator for duct damper – B exhaust air duct*
10. Swegon CASA Smart cooker hood

11. Swegon CASA Smart Modbus GW
12. Swegon CASA Smart control panel (UP1)
13. Swegon CASA Smart control panel (UP2)

*) The use of the duct damper should be judged on the basis of the specific case. The use of the duct damper is recommended at least in the outdoor air duct, especially on the Econo models.

There are three switch inputs on the ventilation unit's PCB that need to be configured. Switch inputs are selected from the Settings menu.

7.4.4 Supervision (DDC)

- DDC control can be enabled/disabled from the control panel's menu Settings/Remote control (DDC).
- Temporary temperature control can be performed by selecting temperature decrease for the operating modes Travelling and Away.
- Variable control occurs between the voltages 2 V - 5 V - 8 V. The ventilation then switches variably between operating modes Away - Home - Boost. Otherwise, control is performed according to the normal DDC control.

8: 0 V (GND)

7: Not used.

6: Fan speed actual value: 0-10 V DC

0 V = Not DDC control

1 V = Travelling

2 V = Away

5 V = Home

8 V = Boost

10 V = Stopped

5: Not used.

4: Fan speed control 0–10 VDC (+/- 0.5 V)

DDC not used = 0 VDC

Travelling = 1 VDC

Away = 2 VDC

Home = 5 VDC


Boosting = 8 VDC

Stopped = 10 VDC

3: Alarms – signal from the ventilation unit (earthed contact)*


2: Emergency stop/fire alarm (if contact between terminals 1–2 is broken, the ventilation unit will stop)*

1: 0 V (GND)



*) Connection of the alarm/emergency stop

7.5 Control diagram



1: Group electrical distribution box | 2: Electrical equipment cubicle | 3: Exhaust air | 4: Outdoor air | 5: Power supply: 230 V, 10 A with plug-in connection | 6: The damming height of the water trap, 100 mm | 7: Supply demarcation of the ventilation unit | 8: Extraction from cooker hood, bypasses the heat exchanger | 9: General ventilation | 10: Supply air | 11: Cooker hood | 12: Modular cables with RJ9-connectors | 13: Control panel

SYMBOL	DESIGNATION	EXPLANATION
T1	TEMPERATURE SENSOR	Temperature sensor, outdoor air
T3	TEMPERATURE SENSOR	Temperature sensor, extract air
T4	TEMPERATURE SENSOR	Temperature sensor, air heater
T5	TEMPERATURE SENSOR	Temperature sensor, exhaust air
TC01	THERMOSTAT	Overheating protection, air heater
TZ03	OVERHEATING PROTECTION	Overheating protection, air heater
HSx.1	CONTACT	Contact, timer for the cooker hood damper
F1	FILTER	Supply air filter
F2	FILTER	Extract air filter
HR	HEAT EXCHANGER	Rotary heat exchanger
SF1	FAN	Supply air fan
EF1	FAN	Extract air fan
RH	REHEATING	Supply air heating, accessory

DESCRIPTION OF THE FUNCTIONS

CONTROL FUNCTIONS:

The ventilation unit can be operated from a separate Smart control panel or a Swegon CASA cooker hood.

When the ventilation unit is controlled from the cooker hood in the Home/Away/Boost modes and for local extraction, the time can be set to 30, 60 or 120 minutes.

The supply air temperature is controlled from the Smart control panel. When necessary, the reheating function can also be switched off from the control panel.


- Overheating protection for the reheating air heater: The air heater is equipped with a TC01 automatic thermostat with manual reset (preset limit value: 90 °C) as protection against overheating.
- The fans have automatic overtemperature protective devices.

REMEDIAL MEASURES TO TAKE IF THE SAFETY EQUIPMENT TRIPS:

- If an overheating protection with manual reset trips, locate and correct the fault; then press the reset button inside the ventilation unit.
- The automatic overheating protections of the fans will reset themselves when the temperature has dropped below the setting value.

7.6 Dimensions

Swegon CASA R3 R



Duct connections				
1	2	3	4	5
Supply air Ø 125	Exhaust Ø 125	Outdoor air Ø 125	Exhaust air Ø 125	Extract air from the cooker hood Ø 100

7.7 Weights


Ventilation unit: 50 kg.

CASA Jazz cooker hood mounted below the ventilation unit: 57.5 kg.

7.8 Ventilation unit codes


R3 Smart R	R03VR00S
R3 Smart L	R03VL00S
R3 Smart R 500 W	R03VR05S
R3 Smart L 500 W	R03VL05S
R3 Smart R 500 W RH	R03VR05S00H
R3 Smart L 500 W RH	R03VL05S00H
R3 Smart R 500 W RH CO ₂	R03VR05S00C
R3 Smart L 500 W RH CO ₂	R03VL05S00C
R3 Smart R 500 W RH VOC	R03VR05S00V
R3 Smart L 500 W RH VOC	R03VL05S00V

Swegon CASA Jazz cooker hood



The illustration shows the right-hand version. On the left-hand version, the duct connection is on the left-hand side.

Ceiling mounting frame (R)



7.9 Accessories for installation

- Smart control panel: SC 10
- Modular cable: PMK 20
- Mounting frame with vapour barrier (R/L): PR085YP
- Condensate discharge tube: 502103
- Water trap: UVL
- Ceiling mounting frame (R): PR085RKA
Ceiling mounting frame (L): PR085LKA
- Replacement filter set of 2 filters F7: PR085FS
- Inspection door cover plate (white): PR085B6V
Inspection door cover plate (stainless steel): PR085B6R
- Swegon CASA Jazz cooker hood for location below the ventilation unit (stainless steel, white)

8. Commissioning form

Function	Factory setting	Setting value
Fan speeds		
Away, supply air fan	60 %	
Away, extract air fan	60 %	
Home, supply air fan	70 %	
Home, extract air fan	70 %	
Boost, supply air fan	85 %	
Boost, extract air fan	85 %	
Maximum automatic boost, supply air fan	100 %	
Maximum automatic boost, extract air fan	100 %	
Smart settings		
Cooling, supply air fan	80 %	
RH, boost limit	5 %	
RH, full boost	30 %	
A+, Home limit	900 ppm	
A+, Away limit	600 ppm	
AQ, boost limit	800 ppm	
AQ maximum boost	1,400 ppm	
Fireplace function, difference in fan speed	20 %	
Cooker hood function, compensation (home)	20 %	
Cooker hood function, compensation (boost change)	0 %	
Central vacuum cleaner function, compensation	20 %	
Airflows NOTE! All the fan modes should be preset.	Project planning values	Setting value
Supply air, total	l/s m³/h	l/s m³/h
Away		
Home		
Boosting		
Extract air, total	l/s m³/h	l/s m³/h
Away		
Home		
Boosting		

Ventilation unit data | Write down the data on the ventilation unit identification plate for reference when the need arises to contact a service company.

Preset by:	Date:



Important

The supply airflow must be 2–10 % lower than the extract airflow.

Remember to explain the use of the item of optional equipment and how to service it to the user/caretaker!

Warranty Conditions

WARRANTOR

Swegon ILTO Oy
Asessorinkatu 10, FI-20780 Kaarina, Finland.

WARRANTY PERIOD

The product has a two (2) year warranty as from the date of purchase.

SCOPE OF THE WARRANTY

The warranty covers defects that have arisen during the warranty period, which have been reported to the manufacturer, or been declared by the warrantor or a representative of the warrantor, and which refers to design, manufacture or material defects as well as consequential defects that have arisen on the product itself. The above mentioned defects are to be cleared by putting the product in working order.

GENERAL WARRANTY LIMITATIONS

The warrantor's warranty liability is limited in accordance with these warranty conditions and the warranty does not cover damages to property or personal injury. The warrantor is not bound to comply with verbal promises in addition to this warranty agreement.

LIMITATIONS ON WARRANTY LIABILITY

This warranty is granted on condition that the product is used in a normal way or under comparable circumstances for the intended purpose, and that the instructions for use have been observed.

The warranty does not cover defects that have been caused by the following:

- Transport of the product.
- Careless use or overloading the product.
- Failure to follow the instructions dealing with installation, operation, maintenance and care.
- Incorrect installation of the product or incorrect location at the place where it is used.
- Circumstances which are not the fault of the warrantor, such as excessive variations in voltage, damage by lightning and fire or other accidents.
- Repairs, maintenance or design modifications that have been done by unauthorized parties.
- Neither does the warranty cover insignificant defects from an operational standpoint such as scratches on surfaces.
- Parts, which through handling or normal wear are exposed to a greater than normal risk of failure, such as lamps, glass, porcelain, paper and plastic parts as well as fuses are not covered by the guarantee.
- The warranty does not cover settings, information about usage, care, service or cleaning which is normally described in the instructions for use or the work required to rectify faults caused by the user neglecting the warning or installation instructions, or investigation of such.

CHARGES DURING THE WARRANTY PERIOD

The authorized service partner will not charge the client for repairs, replaced parts, repair work, transport or travelling expenses necessary for carrying out the repair work that are within the scope of the warranty.

This however assumes the following:

- The defective parts are handed over to the authorized service partner.
- that the repair begins and the work is carried out during normal working hours. The authorized service partner has the right to charge the client for extra costs for urgent repairs, or repairs carried out outside of normal working hours. However if the defects may cause a health risk or substantial economic losses, the defects will be repaired immediately without extra charge.
- A service vehicle or public means of transportation that follows a timetable (boats, planes or snow vehicles are not considered public means of transportation) can be used in conjunction with the repair of the product or replacement of defective parts.
- The costs for dismantling and installation of equipment, which is securely mounted to the place where it is used, cannot be considered as being abnormal.

REMEDIAL MEASURES WHEN A DEFECT HAS BEEN DISCOVERED

If a defect is discovered during the warranty period, the client must without delay report the defect to the dealer or to an authorized service partner (www.swegonhomesolutions.com) or register the fault together with their contact information using the response form at the address www.casahelp.fi. Specify which product has a defect (product model, type designation on the warranty card or on the product identification plate, serial number); describe the type of defect as accurately as possible, and the circumstances under which the defect has arisen. If there is risk that the fault may have consequential impact on the environment, the ventilation unit must be switched off immediately.

A prerequisite for valid warranty liability is that the manufacturer or a representative of the manufacturer is given opportunity to inspect the defects reported in the warranty claim before the repair work begins. A prerequisite for repair under warranty is also that the client, in a satisfactory manner, can prove that the warranty is valid (= written receipt of purchase). After the warranty period has expired, warranty claims, which have not been submitted in writing prior to the expiration date of the warranty period, are not valid.

Swegon ILTO Oy, Asessorinkatu 10, FIN-20780 S:t Karins, www.swegonhomesolutions.com.



DECLARATION OF CONFORMITY

Manufacturer (and if appropriate their authorised representatives):

Company: Swegon ILTO Oy
Address: Asessorinkatu 10, 20780 Kaarina, Finland

Hereby declare that:

Product: The Swegon CASA Smart ventilation units
Type/Model: R3, R5, W3, W4, W5, W9

Complies with the following directives:

The Machinery Directive (2006/42/EU)
The Low Voltage Directive (2014/35/EU)
The EMC Directive (2014/30/EU)
The WEEE Directive (2012/19/EU)
The RoHS Directive (2011/65/EU)

The Ecodesign Directive (2009/125/EU)
Commission regulation 1253/2014
Commission regulation 1254/2014

Following other standards and specifications have been applied:

EN13141-7 (2010)

Person authorized to compile the technical documentation:

Title: Product Group Manager, Lars Norrdal
Address: Asessorinkatu 10, 20780 Kaarina, Finland

Signature:

Place/Date: Kaarina 26.4.2016








Name:

Printed name: Peter Stenström

Title: CEO
Swegon ILTO Oy

Quick Guide

Swegon
Home Solutions



Suomenkielinen Asennus-, käyttöönotto- ja huolto-ohje

löytyy osoitteesta www.swegonhomesolutions.fi (Työkalut > Etsi PDF-tiedosto "R3")



En svenskspråkig Installations-, drifttagnings- och underhållsanvisning

finns på adressen www.swegonhomesolutions.se (Toolbox > Hitta PDF "R3")



En norskspråklig Installasjons-, igangkjørings- og vedlikeholdsveiledning

finnes på adressen www.swegonhomesolutions.no (verktøy > Finn PDF "R3")



Weitere Sprachversionen der Installations-, Inbetriebnahme- und Wartungsanleitung

finden Sie unter www.swegonhomesolutions.de (Toolbox > PDF-Suchmaschine „R3“).



Installation, commissioning and maintenance instruction in English

can be found at www.swegonhomesolutions.com (Toolbox > Find a PDF "R3").